

Truss


A truss is an assembly of beams or other elements that creates a rigid structure.^[1] In engineering, a **truss** is a structure that "consists of two-force members only, where the members are organized so that the assemblage as a whole behaves as a single object".^[2] A "two-force member" is a structural component where force is applied to only two points. Although this rigorous definition allows the members to have any shape connected in any stable configuration, trusses typically comprise five or more triangular units constructed with straight members whose ends are connected at joints referred to as nodes.

In this typical context, external forces and reactions to those forces are considered to act only at the nodes and result in forces in the members that are either tensile or compressive. For straight members, moments (torques) are explicitly excluded because, and only because, all the joints in a truss are treated as revolutes, as is necessary for the links to be two-force members.

A planar truss is one where all members and nodes lie within a two-dimensional plane, while a space truss has members and nodes that extend into three dimensions. The top beams in a truss are called *top chords* and are typically in compression, the bottom beams are called *bottom chords*, and are typically in tension. The interior beams are called *webs*, and the areas inside the webs are called *panels*,^[3] or from graphic statics (see Cremona diagram) *polygons*.^[4]



Truss bridge for a single-track railway, converted to pedestrian use and pipeline support. In this example the truss is a group of triangular units supporting the bridge.



Egyptian ship on the Red Sea, about 1250 B.C. (From Torr's "Ancient Ships.")
Mr. Langton Cole calls attention to the rope truss in this illustration, stiffening the beam of the ship. No other such use of the truss is known until the days of Modern engineering.

An Egyptian ship with a rope truss, the oldest known use of trusses. Trusses did not come into common use until the Roman era.



Typical detail of a steel truss, which is considered as a revolute joint

Contents

Etymology

Characteristics

Simple truss

Planar truss

Space frame truss

Types

Warren truss

Octet truss

[Pratt truss](#)
[Bowstring truss](#)
[King post truss](#)
[Lenticular truss](#)
[Town's lattice truss](#)
[Vierendeel truss](#)

[Statics](#)

[Analysis](#)

[Forces in members](#)
[Design of members](#)
[Design of joints](#)

[Applications](#)


[Post frame structures](#)

[Gallery](#)

[See also](#)

[References](#)

[External links](#)



Historical detail of a steel truss with an actual revolute joint

Etymology

Truss derives from the [Old French](#) word *trousse*, from around 1200, which means "collection of things bound together".^{[5][6]} The term *truss* has often been used to describe any assembly of members such as a [cruck frame](#)^{[7][8]} or a couple of rafters.^{[9][10]} One engineering definition is: "A truss is a single plane framework of individual structural member [sic] connected at their ends of forms a series of triangle [sic] to span a large distance".^[11]

Characteristics

A truss consists of typically (but not necessarily) straight members connected at joints, traditionally termed *panel points*. Trusses are typically (but not necessarily^[12]) composed of triangles because of the structural stability of that shape and design. A triangle is the simplest geometric figure that will not change shape when the lengths of the sides are fixed.^[13] In comparison, both the angles and the lengths of a four-sided figure must be fixed for it to retain its shape. The joint at which a truss is designed to be supported is commonly referred to as the [Munter Point](#).

Simple truss

The simplest form of a truss is one single triangle. This type of truss is seen in a [framed](#) roof consisting of [rafters](#) and a ceiling [joist](#),^[14] and in other mechanical structures such as [bicycles](#) and aircraft. Because of the stability of this shape and the methods of analysis used to calculate the forces within it, a truss composed entirely of triangles is known as a simple truss.^[15] However, a simple truss is often defined more restrictively by demanding that it can be constructed through successive addition of pairs of members, each connected to two existing joints and to each other to form a new joint, and this definition does not require a simple truss to comprise only triangles.^[12] The traditional diamond-shape bicycle frame, which utilizes two conjoined triangles, is an example of a simple truss.^[16]

Planar truss

A planar truss lies in a single plane.^[15] Planar trusses are typically used in parallel to form roofs and bridges.^[17]

The depth of a truss, or the height between the upper and lower chords, is what makes it an efficient structural form. A solid girder or beam of equal strength would have substantial weight and material cost as compared to a truss. For a given span, a deeper truss will require less material in the chords and greater material in the verticals and diagonals. An optimum depth of the truss will maximize the efficiency.^[18]



Planar roof trusses

Space frame truss

A space frame truss is a three-dimensional framework of members pinned at their ends. A tetrahedron shape is the simplest space truss, consisting of six members that meet at four joints.^[15] Large planar structures may be composed from tetrahedrons with common edges, and they are also employed in the base structures of large free-standing power line pylons.



Simple tetrahedron




Diagram of a planar space frame such as used for a roof



This electrical pylon is a three-dimensional truss structure



The roof trusses of the Basilica di Santa Croce in Florence

Types

For more truss types, see truss types used in bridges.

There are two basic types of truss:

- The pitched truss, or common truss, is characterized by its triangular shape. It is most often used for roof construction. Some common trusses are named according to their "web configuration". The chord size and web configuration are determined by span, load and spacing.
- The parallel chord truss, or flat truss, gets its name from its parallel top and bottom chords. It is often used for floor construction.

A combination of the two is a truncated truss, used in hip roof construction. A metal plate-connected wood truss is a roof or floor truss whose wood members are connected with metal connector plates.

Warren truss



Truss members form a series of equilateral triangles, alternating up and down. Main article: Warren truss

Octet truss

Truss members are made up of all equivalent equilateral triangles. The minimum composition is two regular tetrahedrons along with an octahedron. They fill up three dimensional space in a variety of configurations.

Pratt truss



The Pratt truss was patented in 1844 by two Boston railway engineers,^[19] Caleb Pratt and his son Thomas Willis Pratt.^[20] The design uses vertical members for compression and diagonal members to respond to tension. The Pratt truss design remained popular as bridge designers switched from wood to iron, and from iron to steel.^[21] This continued popularity of the Pratt truss is probably due to the fact that the configuration of the members means that longer diagonal members are only in tension for gravity load effects. This allows these members to be used more efficiently, as slenderness effects related to buckling under compression loads (which are compounded by the length of the member) will typically not control the design. Therefore, for given planar truss with a fixed depth, the Pratt configuration is usually the most efficient under static, vertical loading.

The Southern Pacific Railroad bridge in Tempe, Arizona is a 393 meter (1,291 foot) long truss bridge built in 1912.^{[22][23]} The structure is composed of nine Pratt truss spans of varying lengths. The bridge is still in use today.

The Wright Flyer used a Pratt truss in its wing construction, as the minimization of compression member lengths allowed for lower aerodynamic drag.^[24]

Bowstring truss

Named for their shape, bowstring trusses were first used for arched truss bridges, often confused with tied-arch bridges.

Thousands of bowstring trusses were used during World War II for holding up the curved roofs of aircraft hangars and other military buildings. Many variations exist in the arrangements of the members connecting the nodes of the upper arc with those of the lower, straight sequence of members, from nearly isosceles triangles to a variant of the Pratt truss.



A large timber Howe truss in a commercial building



Tempe Salt River Southern Pacific Railroad bridge

King post truss



One of the simplest truss styles to implement, the king post consists of two angled supports leaning into a common vertical support.



The queen post truss, sometimes *queenpost* or *queenspost*, is similar to a king post truss in that the outer supports are angled towards the centre of the structure. The primary difference is the horizontal extension at the centre which relies on beam action to provide mechanical stability. This truss style is only suitable for relatively short spans.^[25]

Lenticular truss

Lenticular trusses, patented in 1878 by William Douglas (although the Gaunless Bridge of 1823 was the first of the type), have the top and bottom chords of the truss arched, forming a lens shape. A lenticular pony truss bridge is a bridge design that involves a lenticular truss extending above and below the roadbed.

Town's lattice truss



American architect Ithiel Town designed Town's Lattice Truss as an alternative to heavy-timber bridges. His design, patented in 1820 and 1835, uses easy-to-handle planks arranged diagonally with short spaces in between them, to form a lattice.

Vierendeel truss

The Vierendeel truss is a structure where the members are not triangulated but form rectangular openings, and is a frame with fixed joints that are capable of transferring and resisting bending moments. As such, it does not fit the strict definition of a truss (since it contains non-two-force members): regular trusses comprise members that are commonly assumed to have pinned joints, with the implication that no moments exist at the jointed ends. This style of structure was named after the Belgian engineer Arthur Vierendeel,^[26] who developed the design in 1896. Its use for bridges is rare due to higher costs compared to a triangulated truss.

The utility of this type of structure in buildings is that a large amount of the exterior envelope remains unobstructed and can be used for windows and door openings. In some applications this is preferable to a braced-frame system, which would leave some areas obstructed by the diagonal braces.

Statics



A bowstring truss is used on the oldest metal bridge in Virginia



The Waterville Bridge in Swatara State Park in Pennsylvania is a lenticular truss



A Vierendeel bridge, which lacks diagonal elements in the primary structure

A truss that is assumed to comprise members that are connected by means of pin joints, and which is supported at both ends by means of hinged joints or rollers, is described as being statically determinate. Newton's Laws apply to the structure as a whole, as well as to each node or joint. In order for any node that may be subject to an external load or force to remain static in space, the following conditions must hold: the sums of all (horizontal and vertical) forces, as well as all moments acting about the node equal zero. Analysis of these conditions at each node yields the magnitude of the compression or tension forces.

Trusses that are supported at more than two positions are said to be statically indeterminate, and the application of Newton's Laws alone is not sufficient to determine the member forces.

In order for a truss with pin-connected members to be stable, it does not need to be entirely composed of triangles.^[12] In mathematical terms, we have the following necessary condition for stability of a simple truss:

$$m \geq 2j - r \quad (\text{a})$$

where m is the total number of truss members, j is the total number of joints and r is the number of reactions (equal to 3 generally) in a 2-dimensional structure.

When $m = 2j - 3$, the truss is said to be *statically determinate*, because the $(m+3)$ internal member forces and support reactions can then be completely determined by $2j$ equilibrium equations, once we know the external loads and the geometry of the truss. Given a certain number of joints, this is the minimum number of members, in the sense that if any member is taken out (or fails), then the truss as a whole fails. While the relation (a) is necessary, it is not sufficient for stability, which also depends on the truss geometry, support conditions and the load carrying capacity of the members.

Some structures are built with more than this minimum number of truss members. Those structures may survive even when some of the members fail. Their member forces depend on the relative stiffness of the members, in addition to the equilibrium condition described.

Analysis

Because the forces in each of its two main girders are essentially planar, a truss is usually modeled as a two-dimensional plane frame. However if there are significant out-of-plane forces, the structure must be modeled as a three-dimensional space.

The analysis of trusses often assumes that loads are applied to joints only and not at intermediate points along the members. The weight of the members is often insignificant compared to the applied loads and so is often omitted; alternatively, half of the weight of each member may be applied to its two end joints. Provided that the members are long and slender, the moments transmitted through the joints are negligible, and the junctions can be treated as "hinges" or "pin-joints".

Under these simplifying assumptions, every member of the truss is then subjected to pure compression or pure tension forces – shear, bending moment, and other more-complex stresses are all practically zero. Trusses are physically stronger than other ways of arranging structural elements, because nearly every material can resist a much larger load in tension or compression than in shear, bending, torsion, or other kinds of force.



Cosmonaut Alexander Serebrov sets up an integrated truss structure "Rapana" at Mir space station, September 16, 1993


These simplifications make trusses easier to analyze. Structural analysis of trusses of any type can readily be carried out using a matrix method such as the direct stiffness method, the flexibility method, or the finite element method.

Forces in members

Illustrated is a simple, statically determinate flat truss with 9 joints and $(2 \times 9) - 3 = 15$ members. External loads are concentrated in the outer joints. Since this is a symmetrical truss with symmetrical vertical loads, the reactive forces at A and 9 are vertical, equal, and half the total load.

The internal forces in the members of the truss can be calculated in a variety of ways, including graphical methods:

- Cremona diagram
- Culmann diagram
- Ritter analytical method (method of sections)



Cremona diagram for a plane truss

Design of members

A truss can be thought of as a beam where the web consists of a series of separate members instead of a continuous plate. In the truss, the lower horizontal member (the *bottom chord*) and the upper horizontal member (the *top chord*) carry tension and compression, fulfilling the same function as the flanges of an I-beam. Which chord carries tension and which carries compression depends on the overall direction of bending. In the truss pictured above right, the bottom chord is in tension, and the top chord in compression.

The diagonal and vertical members form the *truss web*, and carry the shear stress. Individually, they are also in tension and compression, the exact arrangement of forces is depending on the type of truss and again on the direction of bending. In the truss shown above right, the vertical members are in tension, and the diagonals are in compression.

In addition to carrying the static forces, the members serve additional functions of stabilizing each other, preventing buckling. In the adjacent picture, the top chord is prevented from buckling by the presence of bracing and by the stiffness of the web members.

The inclusion of the elements shown is largely an engineering decision based upon economics, being a balance between the costs of raw materials, off-site fabrication, component transportation, on-site erection, the availability of machinery and the cost of labor. In other cases the appearance of the structure may take on greater importance and so influence the design decisions beyond mere matters of economics. Modern materials such as prestressed concrete and fabrication methods, such as automated welding, have significantly influenced the design of modern bridges.

Once the force on each member is known, the next step is to determine the cross section of the individual truss members. For members under tension the cross-sectional area A can be found using $A = F \times \gamma / \sigma_y$, where F is the force in the member, γ is a safety factor (typically 1.05 but depending on building codes) and σ_y is the yield tensile strength of the steel used.



Truss sections stabilize this building under construction in Shanghai and will house mechanical floors

The members under compression also have to be designed to be safe against buckling.

The weight of a truss member depends directly on its cross section—that weight partially determines how strong the other members of the truss need to be. Giving one member a larger cross section than on a previous iteration requires giving other members a larger cross section as well, to hold the greater weight of the first member—one needs to go through another iteration to find exactly how much greater the other members need to be. Sometimes the designer goes through several iterations of the design process to converge on the "right" cross section for each member. On the other hand, reducing the size of one member from the previous iteration merely makes the other members have a larger (and more expensive) safety factor than is technically necessary, but doesn't *require* another iteration to find a buildable truss.

The effect of the weight of the individual truss members in a large truss, such as a bridge, is usually insignificant compared to the force of the external loads.

Design of joints

After determining the minimum cross section of the members, the last step in the design of a truss would be detailing of the bolted joints, e.g., involving shear stress of the bolt connections used in the joints. Based on the needs of the project, truss internal connections (joints) can be designed as rigid, semi rigid, or hinged. Rigid connections can allow transfer of bending moments leading to development of secondary bending moments in the members.

Applications

Post frame structures

Component connections are critical to the structural integrity of a framing system. In buildings with large, clearspan wood trusses, the most critical connections are those between the truss and its supports. In addition to gravity-induced forces (a.k.a. bearing loads), these connections must resist shear forces acting perpendicular to the plane of the truss and uplift forces due to wind. Depending upon overall building design, the connections may also be required to transfer bending moment.

Wood posts enable the fabrication of strong, direct, yet inexpensive connections between large trusses and walls. Exact details for post-to-truss connections vary from designer to designer, and may be influenced by post type. Solid-sawn timber and glulam posts are generally notched to form a truss bearing surface. The truss is rested on the notches and bolted into place. A special plate/bracket may be added to increase connection load transfer capabilities. With mechanically-laminated posts, the truss may rest on a shortened outer-ply or on a shortened inner-ply. The later scenario places the bolts in double shear and is a very effective connection.



A type of truss used in roofing

Gallery



The Hong Kong Bank of China Tower has an externally visible truss structure

The HSBC Main Building, Hong Kong has an externally visible truss structure

Support structure under the Auckland Harbour Bridge


The Auckland Harbour Bridge seen from Watchman Island to its west



Little Belt: a truss bridge in Denmark

Pre-fabricated steel bow string roof trusses built in 1942 for war department properties in Northern Australia

Roof truss in a side building of Cluny Abbey, France




A section through a queen post timber roof truss



A space truss carrying a floor in The Woodlands Mall



Electricity pylon




Timber roof truss



Modern temporary bridge made of Bailey bridge truss panels in Montreal Québec



Three dimensional truss construction made by UnicRotarex® (<https://www.unicrotarex.com/metal-truss/>)



Example of calculation truss forces made by program that use matrix Gauss solving method

See also

- Lattice tower
- Andreini tessellations, the only 28 ways to fill 3D space with trusses that have *identical* joints everywhere
- Brown truss
- Geodesic dome, a truss in the shape of a sphere
- Structural mechanics
- Serrurier truss, a truss form used for telescopes
- Stress:
 - Compressive stress
 - Tensile stress
- Structural steel
- Tensegrity truss, a truss where no compression member touches any other compression member
- Truss rod, a guitar part

References

1. "Definition of TRUSS" (<https://www.merriam-webster.com/dictionary/truss>).
2. Plesha, Michael E.; Gray, Gary L.; Costanzo, Francesco (2013). *Engineering Mechanics: Statics* (2nd ed.). New York: McGraw-Hill Companies Inc. pp. 364–407. ISBN 978-0-07-338029-2.

3. Ching, Frank. *A Visual Dictionary of Architecture*. 2nd ed. Hoboken, N.J.: Wiley, 2012. 277. Print. [ISBN 9780470648858](#)
4. Bow R. H., *Economics of construction in relation to framed structures*. Spon, London, 1873
5. Reif, F., [etymonline.com \(http://www.etymonline.com/index.php?term=truss\)](http://www.etymonline.com/index.php?term=truss) (1965).
6. Oxford English Dictionary
7. Noble, Allen George. *Traditional buildings a global survey of structural forms and cultural functions*. London: I.B. Tauris; 2007. 115. [ISBN 1845113055](#)
8. Davies, Nikolas, and Erkki Jokiniemi. *Dictionary of architecture and building construction*. Amsterdam: Elsevier/Architectural Press, 2008. 394. [ISBN 0750685026](#)
9. Davies, Nikolas, and Erkki Jokiniemi. *Architect's illustrated pocket dictionary*. Oxford: Architectural Press, 2011. 121. [ISBN 0080965377](#)
10. Crabb, George. *Universal Technological Dictionary Or Familiar Explanation of the Terms used in All Arts and Sciences...*, Volume 1 London: 1823. Couples.
11. Shekhar, R. K. Chandra. *Academic dictionary of civil engineering*. Delhi: Isha Books, 2005. 431. [ISBN 8182051908](#)
12. Beer, Ferd; Johnston, Russ (2013). *Vector Mechanics for Engineers: Statics* (10th ed.). New York, NY: McGraw-Hill. pp. 285–313. [ISBN 978-0-07-740228-0](#).
13. Ricker, Nathan Clifford (1912) [1912]. *A Treat on Design and Construction of Roofs* (<https://archive.org/details/atreatiseondesi00rickgoog>). New York: J. Wiley & Sons. p. 12 (<https://archive.org/details/atreatiseondesi00rickgoog/page/n34>). Retrieved 2008-08-15.
14. Maginnis, Owen Bernard (1903). *Roof Framing Made Easy* (<https://archive.org/details/roframingmadeea01magigoog>) (2nd ed.). New York: The Industrial Publication Company. p. 9 (<https://archive.org/details/roframingmadeea01magigoog/page/n13>). Retrieved 2008-08-16.
15. Hibbeler, Russell Charles (1983) [1974]. *Engineering Mechanics-Statics* (3rd ed.). New York: Macmillan Publishing Co., Inc. pp. 199–224. [ISBN 0-02-354310-8](#).
16. Wingerter, R., and Lebossiere, P., *ME 354, Mechanics of Materials Laboratory: Structures*, University of Washington (February 2004), p.1
17. Lubliner, Jacob; Papadopoulos, Panayiotis (2016-10-23). *Introduction to Solid Mechanics: An Integrated Approach* (<https://books.google.com/?id=fhJADQAAQBAJ&pg=PA128&dq=Planar+trusses+are+typically+used+in+parallel+to+form+roofs+and+bridges#v=onepage&q=Planar%20trusses%20are%20typically%20used%20in%20parallel%20to%20form%20roofs%20and%20bridges&f=false>). Springer. [ISBN 9783319188782](#).
18. Merriman, Mansfield (1912) [192]. *American Civil Engineers' Pocket Book* (<https://books.google.com/books?id=AUVIAAAAIAAJ>). New York: J. Wiley & Sons. p. 785. Retrieved 2008-08-16. "The Economic Depth of a Truss is that which makes the material in a bridge a minimum."
19. *Bethanga Bridge* (http://www.heritage.nsw.gov.au/07_subnav_01_2.cfm?itemid=5056556) at the NSW Heritage Office (<http://www.heritage.nsw.gov.au>); retrieved 2008-Feb-06
20. *A Brief History of Covered Bridges in Tennessee* (<http://www.tdot.state.tn.us/bridges/historybridges.htm>) at the Tennessee Department of Transportation (<http://www.tdot.state.tn.us>); retrieved 2008-Feb-06
21. *The Pratt Truss* (<http://www.sha.state.md.us/keepingcurrent/maintainRoadsBridges/bridges/OPPE/historicBridgesIV-Pratt.pdf>) Archived (<https://web.archive.org/web/20080528131942/http://www.sha.state.md.us/keepingcurrent/maintainRoadsBridges/bridges/OPPE/historicBridgesIV-Pratt.pdf>) 2008-05-28 at the *Wayback Machine* courtesy of the Maryland Department of Transportation (<http://www.sha.state.md.us>); retrieved 2008-Feb-6
22. "1. Southern Pacific Railroad Bridge, Ash Avenue Bridge and Mill Avenue Bridge from Tempe Butte looking northwest. - Arizona Eastern Railroad Bridge, Spanning Salt River, Tempe, Maricopa County, AZ" (<https://www.loc.gov/resource/hhh.az0240.photos>). *Library of Congress, Washington, D.C. 20540 USA*. Retrieved 26 March 2020.

23. *Tempe Historic Property Survey* (http://www.tempe.gov/museum/Tempe_history/properties/hps228.htm) Archived (https://web.archive.org/web/20071110232206/http://www.tempe.gov/museum/Tempe_history/properties/hps228.htm) 2007-11-10 at the *Wayback Machine* at the *Tempe Historical Museum* (<http://www.tempe.gov/museum/>); retrieved 2008-Feb-06
24. Dario Gasparini, Case Western Reserve University. *The Wright Brothers and the Pratt Truss* (http://www.woodcenter.org/docs/dayton-conference/Gasparini__WrightBrothersPrattTruss.pdf), presentation slides
25. Covered Bridge's Truss Types (http://www.dot.state.oh.us/se/coveredbridges/truss_types.htm) Archived (https://web.archive.org/web/20080512012401/http://www.dot.state.oh.us/se/coveredbridges/truss_types.htm) 2008-05-12 at the *Wayback Machine*
26. *Vierendeel bruggen* (<http://users.telenet.be/karel.roose/vierendeel/vierendeel.html>)

External links

Retrieved from "<https://en.wikipedia.org/w/index.php?title=Truss&oldid=976005543>"

This page was last edited on 31 August 2020, at 17:13 (UTC).

Text is available under the Creative Commons Attribution-ShareAlike License; additional terms may apply. By using this site, you agree to the Terms of Use and Privacy Policy. Wikipedia® is a registered trademark of the Wikimedia Foundation, Inc., a non-profit organization.